INSTRUCTION AND PARTS MANUAL



FERTILISER SPREADERS (400mm wide floor-belt)

All models from 2018



This Instruction and Parts Manual covers all SAM Fertiliser Spreaders fitted with a 400mm floor-belt manufactured since 2018.

For all other SAM Machinery Instruction Manuals please visit www.sammachinery.co.nz

SERIAL NUMBER

All SAM Machinery products are identified with a unique serial number located on the front of the machine (e.g. '18 S 1234'). Please include this number with all parts and servicing enquiries so we can provide you with fast and accurate assistance.



INTRODUCTION

Coombridge & Alexander have created SAM Fertiliser Spreaders from over 70 years' experience making agricultural machinery in New Zealand. SAM's set the benchmark for Spreaders in New Zealand. Strong, simple and smart, each machine is handcrafted from the very best materials and componentry we can find. They are known for their practical design and easy to use operation.

A family-owned and operated company, located in the heart of the Waikato, Coombridge & Alexander control the complete manufacturing process of the iconic SAM range: Fertiliser Spreaders, Combo Spreaders, Orchard Spreaders, Feed Wagons, Hydraulic Trailers and Quick Hitches.

We stand by the quality of all of our products - our team have put the hard work in so you can expect a long working life out of your gear. All the best with your new SAM. We trust you will love it.

For all parts, servicing or support enquiries please contact us on 07 847 8492.

For international parts and servicing please contact 0064 7 847 8492.

www.sammachinery.co.nz

MODEL DETAILS

MODEL	
SERIAL NUMBER	



QUALITY GUARANTEE

SAM Machinery products are guaranteed against any defects in either material or manufacture for a period of 24 months from delivery date, provided that the equipment is properly maintained and has not been subject to abuse or misuse, operated incorrectly, over loaded or used for purposes other than for which the equipment is designed or is not maintained correctly or if fitted with other than genuine parts.

Claims are only valid when approved by the manufacturer. No person or agent is authorised to assume any liability.

As the use of the equipment is outside our control we can only guarantee quality. No liability for loss, direct expenses incurred from the use of this equipment or from any other cause of in respect of performance etc. can be accepted.

Defective parts must be returned freight paid to the manufacturer or available to be inspected as directed. Should such parts prove to the manufacturers satisfaction to be faulty - repair of - replacement of defective parts shall constitute fulfillment of guarantee obligations. Parts destroyed, lost or tampered with nullify guarantee.

WARRANTY

SAM Machinery products as designed and supplied by Coombridge & Alexander Ltd are warranted against faulty workmanship and defective materials for a period of 24 months from date of purchase. Such warranty is subject to the following conditions:

- 1. This warranty covers the repair or replacement of parts or machinery sold by Coombridge & Alexander Ltd and damaged as a result of faulty workmanship of materials in such part of machinery. It does not extend to any other loss or damage including consequential loss or damage to other property or persons, or damage through poor maintenance.
- 2. No responsibility will be accepted for repairs made other than by Coombridge & Alexander Ltd or its accredited agent and without prior authorisation by Coombridge & Alexander Ltd.
 - a. Without limiting the generality of paragraph 1. above, this warranty does not cover the following;
 - b. Losses sustained through delay in delivery
 - c. Travel expenses
 - d. Damage caused by accident, misuse or abuse
- 3. Damage to any goods which have been altered or modified by someone other than Coombridge & Alexander Ltd or its authorised dealers.
- 4. Procedure for recovery under warranty;
 - 1. No loss or damage will be covered under warranty unless the following procedure is followed by the purchaser.
 - 1. If the purchaser is an authorised dealer
 - a. Coombridge & Alexander Ltd must first be advised of details of the goods concerned, the loss or damage sustained and the circumstances in which the loss or damage arose.
 - b. Coombridge & Alexander Ltd will then decide if such loss or damage is within the terms of warranty and shall advise the dealer as to how the loss or damage is to be repaired.
 - 2. If the purchase is not an authorised dealer
 - a. The loss or damage should be reported directly to Coombridge & Alexander Ltd who will advise whether it is covered by the warranty and direct the purchaser accordingly as to what action is to be taken.



BASIC SAFETY



Many agricultural machines have potentially dangerous moving parts, which can cause serious or fatal injuries. Remember;

- 1. Read ALL warning labels on the machine and ensure you understand operating instructions
- 2. Turn off the tractor before removing any guards, blockages or servicing the machine
- 3. Never use your hands or fingers to check for hydraulic oil leaks
- 4. Keep at least 15 metres distance from the spinner discs when operating
- 5. Do not use the machine in steep areas where there is a high-risk of rollover occurring.

OPERATIONAL CHECK

Before you start work with a machine there are a few basic checks that can be carried out. Ask yourself:

- 1. Is the machine you intend to use suitable for the job e.g. in good working order and safe to use?
- 2. Are all safety devices such as guards in place and working correctly?
- 3. Are there any known mechanical defects pay particular attention to items such as wheels and tyres, and moving parts?
- 4. Are you (or the operator) properly trained to do this job/use this machine?
- 5. Has the instruction manual for the machine been provided, read and understood?
- 6. Is the right personal protective equipment (PPE) available and worn?
- 7. Has a risk assessment been carried out?
- 8. Has the work been properly planned and communicated to those who may be at risk?
- 9. Is the machine operator competent to do the job safely?
- 10. Hitching and attachment points for trailed machinery check that it has been safely attached to the towing vehicle such as a tractor. Pay attention to the condition of drawbar/pick-up hitch, and hitch rings, pins, clips etc.
- 11. Carry out any pre-use checks as specified.

HEALTH & SAFETY RISK ASSESSMENT

A hazard identification, assessment and control procedure has been conducted on a representative SAM Fertiliser Spreader and where necessary appropriate risk control measures have been outlined below;

HAZARD	HARM	CONTROLS
Contact, impact or entanglement from moving parts/ loose objects inc. gears, chains, sprockets, spinner shafts and discs, and wheels.	 Deep cuts or amputation Bruising Fractures 	Avoid wearing loose clothing, jewelery or gloves - they increase the risk of entanglement. Stand a safe distance from the machine when under operation.
Leaking hydraulic hoses and/or couplings.	 Leaking oil may get into skin Skin and eye irritation Breathing difficulties 	Apply a programme preventive maintenance (hydraulic hoses and hydraulic hose couplings). Leaking oil, or bulging or abraded hose walls, must have faulty parts replaced. Never use hands or fingers to detect leaks. Wear appropriate PPE (personal protective equipment).
Tractor and/or Fertiliser Spreader roll-over due to instability under varying conditions and terrain.	 Serious injury Fatality 	Do not use the machine in steep areas, or on unstable ground.





To keep your SAM Spreader in excellent working condition, please follow these basic maintenance procedures as you go.

- 1. Keep your machine fairly clean and very well greased.
- 2. Before each use; check the hydraulic system for signs of oil leaks or wear. Check there is no play in the spinner bearings by lifting up on the spinner discs. Tension the spinner bearings by tightening the large nyloc nut at the top of the spinner shaft (this can be adjusted by undoing the grub screws).
- 3. After every five hours of operation grease all nipples on the front and back floor shafts, and the four spinner shaft bearings should be well greased.
- 4. After every ten hours of operation check all bolts are tight, including the wheel nuts, joiners and spinner discs and vanes. Check all nipples and grease points on the front floor adjusters slides, drawbar jack, clutch pivot bearings, back door jack, hubs and tandem axle pivot points.
- 5. The floor-belt should be tensioned with a 40mm sag below the middle of the chassis, with an even curve/sag from front to back. Adjust when necessary.
- 6. All roller chains should be kept well oiled, particularly during long periods of storage.
- 7. Check the couplings above the spinner tubes stay approximately 2mm between the top and bottom halves.
- 8. Check your linkage/tow pins.
- 9. Use the mesh insert mounted inside the spreader bin for urea. This protects the floor mat and spinner mechanisms from hard lumps. You can also leave in for other products to protect from foreign objects e.g. rocks and wood. If you are having trouble with Urea blocking the back door exit, a sheet of chickenwire with 1.5cm gaps (or similar) can be fixed to the existing mesh grill to act as a sieve.
- 10. Always ensure tractor oils are kept in excellent condition. Beware when changing a Spreader between different tractors. Pump oil out of the hoses unless they use the same hydraulic oil.
- 11. If you have load cells, please make sure the bolts are regularly tightened.
- 12. Avoid high pressure hosing/waterblasting around your load cells and monitor.

Please keep these checks up for the lifetime of your SAM.



Before starting work with your SAM Fertiliser Spreader please read the following application and set-up instructions to ensure safe and productive operation.

SPREAD RATE SETTING

The required fertiliser application rate can be set by adjusting the back door jack and viewing the spread rate sticker to achieve the desired rate per hectare. The floor-belt speed is ground-driven from the wheel ensuring the application rate at the desired back door setting will remain constant regardless of tractor speed.

The back door settings on the spread rate sticker are a guide only. Note, various fertiliser products will flow differently. We recommend applying the first bin load of product onto a measured paddock/area and carefully checking application rates to ensure spread rate accuracy.

At the back of this manual we have included a more comprehensive spread rate chart that includes product densities for a selection of known fertiliser products for your reference. The spread rate (back door settings) are typically very similar for fertiliser products of the same density and granule type.

SPREADING CENTRES

We recommend spreading at 15 metre centres for granulated fertiliser products and 10 metre centres for powdered or fine granulated products such as Lime. Within the included spread rate chart we have also included spreading rates at 17.5 and 20 metre centres if required. For fertiliser application rates over 500kg per hectare we suggest selecting closer spreading centres with a lower back door setting.



HYDRAULICS

Standard SAM Fertiliser Spreaders are fitted with two OMP50 hydraulic motors running in series, requiring an external oil flow of 50 litres/minute.

It is very important that you adjust the hydraulic oil flow from the tractor back to 50 litres/minute

if possible (or 70 litres/minute maximum). Two OMP50 hydraulic motors can be run in series with hydraulic oil flows over 70 litres/minute. Note, the higher the bypass oil flow, the higher the pressure in the Fertiliser Spreader's hydraulic system.



COUPLING THE HYDRAULICS

The live hose (red) must be coupled to a high pressure outlet point on the tractors external hydraulic system. This take off point can be fitted to an existing double acting valve already fitted for farm machinery, or a new fitting can be installed.

The return hose (yellow) must be coupled into the same double acting bank using the quick release coupling supplied.

HYDRAULIC OPERATION

To operate the clutch, follow the instructions found on the front of the plastic spreader bin. The floor-belt has an in/out clutch (including a double acting clutch ram) that is activated automatically from the tractor seat when the hydraulic spinners are started.

To start the hydraulic spinners and engage the clutch, pressurise the live (red) hose, this will place the clutch into gear and subsequently start the hydraulic spinners turning.

To stop the hydraulic spinners and place the clutch out of gear, move the hydraulic lever to pressurise the return (yellow) hose for one second then place the lever to neutral.

The hydraulic spinners and valve control must be coupled to the tractors hydraulic system to ensure safe operation. Please contact your local dealership or Coombridge & Alexander directly if there is any doubt. Note, the adjustable control valve on the hydraulic valve block controlling the spinner speed is pre-set in the factory and should not be altered.

Valve Control Settings (Preset)

 Danfoss OMP 50 Motor - running in Series = With the valve completely closed open anti-clockwise 1 7/8 turns out for 850 RPM (then set the lock nut)

ALWAYS ensure tractor oils are kept in excellent condition. Beware when changing a Fertiliser Spreader between different tractors, pump oil out of the hoses unless they use the same hydraulic oil.

Please contact your local dealership or Coombridge & Alexander directly for operational support.

FERTILISER SPREADER CAPACITIES (400mm Floor-Belt)

Spreader Capacity	Fertiliser (m3)	Superphosphate (t)	Lime (t)	Urea (t)
4t Fertiliser Spreader	3.2m3	4t (1.3t/m3 density)	5.5t (1.7t/m3 density)	2.6t (0.8t/m3 density)
5t Fertiliser Spreader	3.9m3	5t (1.3t/m3 density)	6.6t (1.7t/m3 density)	3.1t (0.8t/m3 density)
6t Fertiliser Spreader	4.6m3	6t (1.3t/m3 density)	7.7t (1.7t/m3 density)	3.7t (0.8t/m3 density)



REFERENCE	PART NUMBER	DESCRIPTION	QTY.
	3103	Wheel & Tyre - 11.5/80 x 15.3 (12ply)	
1*	3107	Wheel & Tyre - 400/60 X 15.5 (TR Tread)	2-4
	3948	Wheel & Tyre - 550/60 x 22.5 (16ply)	
2	P250	Chain & Sprocket - Drive Housing S/S (see Ground Drive diagram)	1
3	-	Ground Drive - Gear Assembly (see Ground Drive diagram)	1
4	P4697	Belt & Floor Chain Tension Adjusters - Left/Right	2
5	P3022	Front Shaft (Complete) 1.5" - (inc. Sprockets + Spacer Ring)	1
6	P221	Deadeye Bearing 1.5"	2
7	3526	Front Bin Skirt Rubber	1
8	1609	Serial Number Plate	1
9	3796	Hose Kit - D200	1
10	P1402	Jack Stand (70sq) - DG701	1
	P3145D	Fixed Tow Hitch (12mm Mounting Plate) - 50mm Donut Eye	
	P3145	Fixed Tow Hitch (12mm Mounting Plate) - 37mm Ball Eye	
11*	P3557	Swivel Tow Hitch (12mm Mounting Plate & insert)	1
	P4926	Swivel Tow Hitch (12mm Mounting Plate) - 50mm Donut Eye (no insert)	
	P2102	Swivel Tow Hitch (20mm Mounting Plate & insert)	
12*	-	Hub & Stub	2-4

MACHINE SIDE-VIEW - DRIVE

* Wheel & Tyre, Tow Hitch and Hub & Stub set-up varies depending on machine model, size and year of manufacture.





MACHINE REAR-VIEW - SPINNER SET-UP

REFERENCE	PART NUMBER	DESCRIPTION	QTY.
1	P4751	Danfoss OMP50 Hydraulic Motor	2
2*	P3040*	Skirt Pressing (S/S) - (inc. Rubber + Rivets) 2860mm - Left/Right	2
Z	P4686	Skirt Rubber & Rivet Set - x2 (2.77 x 80mm) + 34 Rivets	2
3*	P0391*	Floor-belt and Chain (Complete)	1
4	P202	Spinner Tube Mounting Frame	1
5	P4452	Deflector + Divider S/S Panel (Complete)	1
6	P2809	Back Door Jack (DT490)	1
7	3793	Hydraulic Flow Control Valve - HCV 2197	1
8	P440	Flexi Coupling CA90 - 25mm/1"	2
9*	3424	UNF Nyloc Nut 1 1/4" & Grubscrew 3/8"	2
10	P20C	Spinner Tube - Complete	2
11	P4695	Mollybush Bearing and Housing - Long/Short	2
12	P4664	Back Shaft - 50mm (Complete inc. 5T Sprockets) - For Tandem Axle	1
	P4834	Back Shaft - 50mm (Complete inc. 5T Sprockets) - For Single Axle	1
13*	P620	Spinner Disc 5mm + Vanes (5CR12)	2
14	P621 & P621A	Spinner Vanes (Long) - Left/Right (5CR12)	2
15	P622 & P622A	Spinner Vanes (Short) - Left/Right (5CR12)	2

* Floor-Belt and Chain, Skirt Pressings, Couplings and Back/Front Shafts vary depending on machine model, size and year of manufacture. Please include the machine serial number with all parts and servicing enquiries.





GROUND DRIVE

REFERENCE	PART NUMBER	DESCRIPTION	QTY.
1	4011 & 4012	Bolt 3/4"x5" UNC & Nyloc Nut 3/4" UNC	1
2	4282	Clutch RAM - 2.5" D/A	1
3	P4704	3/4" Stainless Steel Ram Pin & S10 R Clip	1
	P0424	Chain 16B (1" Pitch) - 46 Outer Links + Joiner	1
4 (Enclosed)	3694	Sprocket 30T - 50mm Bore, 1/2" Keyway	1
4 (Enclosed)	P4689	Mollybush Bearings - Gearbox	
	2824 or 4074	Sprocket 11T or 15T, 1.5" Bore, 3/8" Keyway (3)	1
5 & 12	P4668	Drive Gear 48T - 20mm Bisalloy	1
6 & 13	P1005	Shear Plate Assembly Complete with 1.5" ID Boss	1
7	P4669	Drive Gear 22T - Bisalloy - 100mm Bore - 13D	1
8	2396	Sprocket 14T - 100mm Bore16mm	1
9	P4861	Tandem 22T Gear + Sprocket Idler Assembly - No Shaft	1
10	P4788	Hubcap 90mm (70sq) + Grease Nipple	1
11	6362	Sprocket 14T - 5-1/2" Bore (Welded to 125mm BH Pipe)	1
14	P4669	Gear - 22T Bisalloy - 100mm Bore	1
15	P4842	Chain CA550 - 16 Outer Links + 2 Cranks + Joiner	1
	3414	Wheel nut - 70sq hubs	24
	7215	Wheel nut - 80sq hubs	32

TANDEM-AXLE







BEARING SIZES BY HUB MAKE / MODEL

HUB MAKE / MODEL	HUB SIZE	BEARINGS	SEAL	HUB CAP
ADR Mk2	60sq	30211 / 30208	57 x 100 x 10 Mk2	80mm
ADR Mk3	60sq	30211 / 30208	56 x 100 x 10 Mk3	80mm
ADR Mk3	70sq	30213 / 32210	67 x 120 x 10 Mk3	90mm
ADR Braked	70sq Braked	30213 / 32210	67 x 120 Mk1	90mm
ADR Mk3	80sq	32215 / 32212	77 x 130 x 10 Mk3	110mm
ADR Mk5	60sq	30211 / 30208	73 x 100 x 13 Mk5	80mm
ADR Mk5	70sq	30213 / 32210	93 x 120 x 13 Mk5	90mm
ADR Mk6	60sq	30211 / 30208	56 x 100 Mk6	82mm - Screw on
ADR Mk6	70sq	30213 / 32210	67 x 120 Mk6	92mm - Screw on
ADR Mk6	80sq	32215 / 32212	77 x 130 Mk6	124mm (+ Cap Screws)
ADR Mk7	60sq	30211 / 30208	80 x 100 x 8	82mm - Screw on
ADR Mk7	70sq	30213 / 32210	100 x 120 x 8	Screw on
ADR Mk7	80sq	32215 / 32212	110 x 130 x 8	124mm (+ Cap Screws)
FAD	60sq	30211 / 30208	70 x 100 x 10	80mm
FAD	70sq	30213 / 30210	80 x 120 x 12	90mm
FAD	80sq	32215 / 32211	90 x 130 x 12	100mm
TVS	60sq	30211 / 30208	80 x 100 x 12	80mm
TVS	70sq	32213 / 32210	90 x 120 x 12	90mm
TVS Braked	70sq & 80sq	Check	Check	90mm & 110mm
TVS	80sq	32215 / 32212	100 x 130 x14	110mm
Monroc	60sq	30211 / 30207	72 x 105 x 10	73.5mm - Screw on
Monroc	80sq	30215 / 32211	95 x 135 x 14	101.5mm - Screw on

COMMON BEARING SIZES AND DIMENSIONS

BEARING	INTERNAL DIAMETER (ID)	OUTSIDE DIAMETER (OD)	WIDTH
30208	40mm	80mm	19.75mm
30210	50mm	90mm	21.75mm
32210	50mm	90mm	24.75mm
30211	55mm	100mm	22.75mm
32211	55mm	100mm	26.75mm
32212	60mm	110mm	29.75mm
30213	65mm	120mm	24.75mm
32213	65mm	120mm	32.75mm
32215	75mm	130mm	33.25mm
67048 / 010	1.25"	2.328"	0.625"



If you are experiencing a problem or have a question that is not listed in this chart below, please contact Coombridge & Alexander directly or see your local dealership for parts and service.

QUESTION / PROBLEM	SOLUTION		
What hydraulic oil flow is required?	Standard SAM Fertiliser Spreaders are fitted with two OMP50 hydraulic motors running in series, requiring an external oil flow of 50 litres/minute.		
What RPM should the spinner shaft turn at?	The spinner shaft should turn at approx. 850RPM at 50 litres/ minute.		
What direction do the spinner discs turn in?	When standing at the back of the machine, the right-hand spinner disc should turn clockwise and the left-hand spinner disc anti-clockwise.		
How do I prevent fertiliser product falling out the sides and/or front of the spreader bin (e.g. striping)?	The side-skirts (running the length of the machine, inside the plastic bin) and front/rear bin scrapers will require regular adjustment, particularly when the machine is new. Both the side-skirts and front/rear bin scrapers are bolted (slotted holes) onto the machine - these bolts can be simply loosened and the skirt or scraper maneuvered to be flush with the floor- belt.		
What tension should be on the floor-belt and chain assembly?	The floor-belt should be tensioned with a 40mm sag below the middle of the chassis, with an even curve/sag from front to back.		
What are the minimum and maximum application rates for various fertiliser products?	From 45kg/hectare at 15m spreading centres for Urea (and similar products), and up to 3,000kg/hectare at 10m spreading centres for Lime.		
How accurate is the spread pattern?	Representative machines have been tested using the nationally recognised Spreadmark test for accuracy. Spread patterns are rated using Coefficient of Variation (CV), a measure of the percentage of fertiliser outside a perfect spread - 0% being a perfect spread pattern. New Zealand standards recognise a CV under 15% as acceptable for nitrogenous fertilisers (DAP, Urea, Nitroposka Blue etc.). SAM Fertiliser Spreaders have achieved a 7.1% CV for Urea and 8.1% CV for Superphosphate - well within industry standards.		
Why are my gears not meshing properly?	If the clutch ram is mounted under the stainless chain guard check that the ram piston has not unscrewed inside the cylinder thus preventing the ram spear from retracting fully.		



If you are experiencing a problem or have a question that is not listed in this chart below, please contact Coombridge & Alexander directly or see your local dealership for parts and service.

QUESTION / PROBLEM	SOLUTION
What is the spreader bin capacity?	4t Fertiliser Spreader = 3.2m3 of fertiliser 4t of Superphosphate (1.3t/m3 density) 5.5t of Lime (1.7t/m3 density) 2.6t of Urea (0.8t/m3 density) 5t Fertiliser Spreader = 3.9m3 of fertiliser 5t of Superphosphate (1.3t/m3 density) 6.6t of Lime (1.7t/m3 density) 3.1t of Urea (0.8t/m3 density) 6t Fertiliser Spreader = 4.6m3 of fertiliser 6t of Superphosphate (1.3t/m3 density) 7.7t of Lime (1.7t/m3 density) 3.7t of Urea (0.8t/m3 density)
How does the automatic clutch work?	As the hydraulic spinners are engaged (live hose pressurised) oil closes a hydraulic ram inside the clutch assembly engaging the two ground-drive gears to start the floor. When the hydraulic spinners are stopped (return hose pressurised) and the lever returned to neutral, the two ground-drive gears are disengaged stopping the floor-belt. The system can be engaged or disengaged while moving.
What is the life expectancy of the gears?	As the gears only engage at low pressure they should last many thousands of tonnes before requiring replacement.
What paint treatment does the chassis receive?	The chassis is firstly sand-blasted, then thermal-arc spray galvanised, primed, followed by a final two-pot epoxy top-coat.
Can I get different wheel/tyre options?	A variety of tyre options are available for each model. Please contact Coombridge & Alexander Ltd directly for more information.
How do I prevent Urea blocking the back door exit?	A sheet of chicken wire with 1/2"/1.5cm gaps (or similar) can be fixed to the existing mesh grill inside the spreader bin to prevent larger clumps of product blocking the back door exit.



SPREADING TABLES

400 W	ide Mat c	r Low Sp	beed 80	0 Wide	Mat			S	PRE	NID	T T T	BLE	6			S	pread	Widths In Me	tres Ce	entre to Cen	tre
All Rat	es In Kild	ograms F	Per Hect	tare.		Door Se	ettings	1 to 20) (Read	from F	Ruler Le	evel/To	p of th	e Back	Door).	0	heck F	ertiliser Den	sities /	with Manufa	cturer
						DAP			Superp	hospha	te										
	Urea		Sulph	ate of ⊭	Ammonia	Nitrop	ohoska I	Blue	Triple	Super/	Salt	Serpent	ine Sup	D .	olomite	0		eact Rock (Sec	chura)	Lime	
1	Density 0.	.77 t/cubi	c i Densi	ty 1.0 t	/cubic m	Densit	y 1.1 t/o	cubic m	Density	1.2 t/c	ubic m [Density	1.3 t/cu	bic m D	ensity 1	.4 t/cu	bic m D	ensity 1.5 t/c	ubic m [Density 1.6 t/	cubic m
	15 1	7.5 20	12.	5 15	17.5	15	17.5	20	15	17.5	20	15	7.5	20	15 1	7.5	20	10	N/A	10 N/A	
	Spread V	Vidth in N	A Spre	ad Widt	h in M	Sprea	d Width	n in M	Spread	Width	in M	Spread	Width i	n M S	pread	Vidth i	n M S	pread Width	in M	Spread Width	Muic
20	905 7	76 67	9 149:	9 1249	1071	1374	1178	1030	1499	1285	1124	1624	1392	218 1	954 1	675 1	466 3	141		3350	20
19	860 7	37 64	5 142	4 1186	5 1017	1305	1119	979	1424	1220	1068	1542	322	157 1	857 1	591 1	392 2	984		3183	19
18	815 6	398 61	1 134	9 1124	1 963	1236	1060	927	1349	1156	1012	1461	1253 1	096	759 1	508 1	319 2	2827		3015	18
17	769 6	59 57	7 127.	4 1062	910	1168	1001	876	1274	1092	955	1380	183	035 1	661 1	424 1	246	2670		2848	17
16	724 6	21 54:	3 119	666 6	856	1099	942	824	1199	1028	899	1299	113	974 1	563 1	340 1	173 2	2513		2680	16
15	679 5	82 50	9 112	4 937	803	1030	883	773	1124	963	843	1218	044	913 1	466 1	256 1	660	2356		2513	15
14	634 5	43 47	5 104	9 874	749	962	824	721	1049	899	787	1137	974	852 1	368	173 1	026	2198		2345	14
13	588	04 44	1 974	812	696	893	765	670	974	835	731	1055	905	792 1	270 1	089	953 2	2041		2178	13
12	543 4	65 40	7 899	749	642	824	707	618	899	771	674	974	835	731 1	173	005	879 1	884		2010	12
11	498 4	127 37:	824	687	589	756	648	567	824	707	618	893	765	670 1	075	921	806 1	727		1843	1
10	453 3	88 33	9 749	624	535	687	589	515	749	642	562	812	696	609	977	338	733 1	570		1675	10
6	407 3	49 30	5 674	F 562	482	618	530	464	674	578	506	731	626	548	879	754	660 1	413		1508	6
œ	362 3	10 27	2 599	500	428	550	471	412	599	514	450	649	557	487	782	970	586 1	256		1340	8
2	317 2	72 23	8 525	437	375	481	412	361	525	450	393	568	487	426	684	586	513 1	660		1173	2
9	272 2	333 20	450	375	321	412	353	309	450	385	337	487	418	365	586	503	440	942		1005	9
ß	226 1	94 17(0 375	312	268	343	294	258	375	321	281	406	348	304	489	419	366	785		838	ŋ
4	181	55 13	9 300	250	214	275	236	206	300	257	225	325	278	244	391	335	293	628		670	4
m	136 1	16 10;	225	187	161	206	177	155	225	193	169	244	209	183	293	251	220	471		503	n
2	91	78 68	150	125	107	137	118	103	150	128	112	162	139	122	195	168	147	314		335	2
-	45	39 34	1 75	62	54	69	59	52	75	64	56	81	20	61	98	84	73	157		168	-
Door	Setting	S																		Door Se	ettings
			Step	. .	Select	the pr	roduct t	to be sp	oread at	the to	p of th	ie chart	e.g. Sı	Iperpho	osphat∈	: with a	i densit	y of 1.2 tonr	nes per	cubic metre	
Door S	etting In	struction	<u>s</u> Step	∼i	Select	t the s	pread w	ridth fo	r the p	oduct	either	15,17.5	5, or 2() metre	e centra	es e.g	.15 m	etre centres			
			Step	Э	Follow	/ this c	olumn (down to	o select	spread	ding rat	te requi	ired in	kilograr	ns per	hectar	e e.g.	300 kg/h			
			Step	4.	Now F	Follow 1	row acro	oss to f	find doc	or heigh	nt setti	ng on le	eft or ri	ght co	lumns e	e.g. no.	4 Set	: door height			



The spreading table below is fixed beside the back door of each SAM Fertiliser Spreader. The required fertiliser application rate can be set by adjusting the back door jack and viewing the spreading table sticker to achieve the desired rate per hectare - setting the pointers on the back door level with the selected box. The 'DOOR HEIGHT' side scale (1-20cm) represents the opening space (in centimetres) between the floor-belt and the back door.

Set poi Rates a	SPREADING TABLE Set pointer to the centre of the box with the rate required. Rates are in kg per hectare. Detailed spread tables are in your manual.						
	Lime 10m Centres	Super 15m Centres	Urea 15m Centres				
Door Height	Density 1.6 t/cu.m	Density 1.1 t/cu.m	Density .77 t/cu.m	Door Height			
20	3350	1374	905	20 —			
— 19	3183	1305	860	19 —			
18	3015	1236	815	18 —			
- 17	2848	1168	769	17 —			
16	2680	1099	724	16 —			
— 15	2513	1030	679	15 —			
— 14	2345	962	634	14 —			
<u> </u>	2178	893	588	13 —			
<u> </u>	2010	824	543	12 —			
- 11	1843	756	498	11 —			
10	1675	687	453	10 —			
<u> </u>	1508	618	407	9 —			
<u> </u>	1340	550	362	8 —			
— 7	1173	481	317	7 —			
<u> </u>	1005	412	272	6 —			
— 5	838	343	226	5 —			
— 4	670	275	181	4 —			
<u> </u>	503	206	136	3 —			
<u> </u>	335	137	91	2 —			
— 1	168	69	45	1 —			



EXTERNAL BATTERY PACK

The Iconix FX15 Monitor is powered by a 12V external battery pack. Supplied with the Iconix FX15 Monitor is two 12V batteries together with a battery charger (AC adaptor).

Battery life and charging frequency will depend on usage and battery care. We recommend always charging the battery (with the supplied charger) for 6-8 hours.

The Iconix FX15 Monitor can also be powered from the round pin connection (7-pin) designed to fit the tractors auxiliary ply. This connection will power the display while the tractor is running but will not charge the battery.

USER GUIDE

- 1. To turn on the Iconix FX15 Monitor, press the 'ON' button the display should read '0.0' with the '^' symbol underneath the 'ZERO' label.
- 2. When loading is completed the load weight will display in kilograms.
- 3. If the Iconix FX15 Monitor is left 'ON', it will hold the load weight/display until the load starts to discharge. As the load is discharged, the display will provide an accurate reading of the current load throughout the discharge process (subtracting from the initial weight).
- 4. If the Iconix FX15 Monitor is turned 'OFF' before load discharge begins, there are two methods for discharging;

Option 1 - push the 'ON' button - this will retrieve the stored load weight. Discharge or further loading can begin. Please note pushing the 'ZERO' button will clear the stored weight if required.

Option 2 ('Negative' mode) - push the 'ON' button followed by the 'ZERO' button - this will zero the load. As discharge begins the display will show a negative symbol as it counts the kilograms discharged.

Only loads greater than 100kgs can be stored when the Iconix FX15 Monitor is turned 'OFF'.

ICONIX FX15 MONITOR





QUESTION / PROBLEM	SOLUTION
No display on Iconix FX15 Monitor.	 Plug the FX15 Monitor into an alternative power source to eliminate potential battery issues If an external power cable is used, please try another power cable If there is still no reading please try another display to determine if the fault is within the Iconix unit or load-cells. If alternative display works the original unit is likely to be faulty and will need to be returned to the manufacturer for diagnosis and repair.
Four flat lines displaying on Iconix FX15 Monitor. OR The displayed weight is unstable and varies up/down.	 The load-cells are connected in pairs to a junction box by cables, with a main cable extending from the junction box to the FX15 Monitor. The load-cells are paired up - two in the front and two in the back. Disconnect both load cell cables from the junction box If the FX15 Monitor will not 'ZERO', the unit is likely to be faulty and will need to be returned to the manufacturer for diagnosis and repair If the FX15 Monitor zeros, try the following; Plug in one of the two cables that connect to the junction box If the fault reoccurs, remove the first cable and plug in the second. It is unlikely that there will be a fault with multiple cells, and instead you should be able to isolate the exact faulty load-cell 'ZERO' the FX15 Monitor with the good load-cells (one cable) connected Pull down on the top front of the machine to activate the load-cell/s A negative (-) reading indicates the rear cells are working Disconnect the cable (attached to the junction box) for the working load-cells. Disconnect the wires at the junction box for both the load-cells. If the FX15 Monitor zeros, connect each load cell individually checking the display after each connection to ensure a normal reading. This will indicate which of the cells, if not both, are faulty. Replace the faulty load-cell or cells, connect all wires and cables and retest.



SAM SPREADER WEIGHING APP

BLUETOOTH APP NOW AVAILABLE FOR YOUR MOBILE

SAM load weigh scales provide simple, accurate, electronic weighing of feed or fertiliser. They are available as an optional extra on our full range of Spreaders and Feed Wagons.

If you have scales fitted to your Spreader, there is a simple mobile App for you to download. Using bluetooth, you can view the accurate weight of product in your machine on you phone anytime. The App is easy to use and FREE to download. Currently Android only.

Compatible with all FX15's with bluetooth hardware.

Simply go to our website under 'Parts & Servicing' then 'How to' you will see 'How to install your SAM Spreader App'.

You just download the app and away you go.

